



## **Epson TM-T88IV Thermal Receipt Printer – USB Connection Windows XP Install**

Please read these instructions carefully before attempting to install or connect the printer to the computer. You must install the print driver before connecting the printer to the computer as outlined in the steps below.

Before you connect your printer to the computer you must execute the **ATM\_310E.exe** driver. This is an executable file that installs files on your hard drive that you will need to install the printer. Follow the steps outlined below to install this driver.

### **Installing the Print Driver for the Epson TMT88IV Thermal Receipt Printer**

1. If you received a **Driver Resource CD** put the CD into your CD-ROM or CD-RW drive navigate to **Printers > Epson Printers > Epson TM-T88IV > ATM\_310E.exe**. Double-click on the **ATM\_310E.exe** and follow the prompts to complete the install process. If you downloaded the driver from our website double-click on the **ATM\_310E.exe** on your desktop to start the install process.
2. The **Select OS** dialog screen appears, the default is **Windows XP** operating system, and **US** for Select Install Language. Accept the defaults click **Next**.
3. The Select Module dialog box appears put a check mark in **USB Driver** and **Epson TM-T88IV Receipt** printer. Click on the **Printer Port Setting, e.t.c...** button, select **USB** click **OK** then click **Finish**.
4. You must restart you computer for the changes to take effect; click **YES**.

### **Connecting the Epson TM-T88IV Receipt Printer - USB Connection**

**You must connect the printer exactly as outlined for the printer to install correctly.**

1. The computer and the printer must be **ON**. Plug the **USB** cable into the printer then into an available USB port on the computer. If the printer has been connected correctly, a pop-up screen will appear on the lower right-hand corner of the screen stating your new hardware has been installed and is ready to use.

### **Testing the Printer**

1. Click on Start > Settings > Printers and Faxes. If the printer was installed correctly, you will see the printer in the list.
2. Right-click on the Epson Receipt Printer and left-click on Properties. Click on the Print Test Page button to send a test page to the Receipt Printer.

**NOTE:** If you don't see the printer in the printer list, then the driver was not installed correctly and you will need to remove the driver and reinstall.