

HHP IT3800 Setup Sheet

1. 
Factory Default Settings

7. 
Save

2. 
* USB Keyboard (PC)

3. 
Interleaved 2 of 5 * On

Presentation Mode:

~ 0 1 T R G M O D 3 . 3

4. 
Minimum (Default =4)

5. 
0

6. 
8