



Logic Controls Pole Display – USB Interface

Read these instructions carefully before connecting your Pole Display to your computer.

Assembling the Pole Display and connecting the Pole Display to your computer

1. The computer should be **off**.
2. Remove the Pole Display, USB Interface Cable, A/C Adapter and the Metal Base with Mounting Hardware from the box.
3. Lay the Pole Display on a flat surface and remove the covering on the LCD display. The Pole Display can be used in a freestanding mode or attached to the counter using the Mounting Hardware.
4. After you have determined how you are going to attach the Pole Display, connect the USB Interface cable to the cable coming from the bottom of the Pole Display.
5. Remove the A/C Adapter from the box. Connect the A/C Adapter cable to the short cable and plug the other end of the A/C Adapter into a power outlet.
6. Insert the driver CD that came with the Pole Display and connect the USB cable to an available USB port on your computer. When the New Hardware Wizard appears; select, “**Install one of the other drivers**”. Navigate to the CD/RW drive (usually d:). Double-click to open the **Pole Display folder > w2Kcom >** then highlight the **PD3COM.inf** file. Click **next** and then click **Continue Anyway** to finish installing the driver.
7. Right-click on **My Computer** and left-click on **Properties**. Click on the **Hardware** tab to bring to the forefront. Click on **Device Manager** button to open. Navigate to the **Ports (COM's & LPT's)**. Click on the **plus sign** to open and **note** the new **COM** port in the list (usually when you install this driver, it will install COM4 or COM5 in the list). You will need this port number when you configure the port settings for the Pole Display in The Uniform Solution program. Close all the screens back to the desktop (also known as the icon screen).
8. Open The Uniform Solution program go to **Setup > This Computer > Pole Display**.
9. Place a checkmark in the box that says, “ A customer pole display is connected to this computer”. Select the COM port that the Pole Display is to be connected to. You can change the message that appears on the display by replacing the message in the Scrolling Message field and the Flashing Message field. Click ok to save your changes.